



POS	ITEM	DENOMINATION	QUANTITY
			RTC-10-A/H-38 ESP ed.01
1	3786024	Ambient thermostat	1
2	3795044	Motor-driven fan	1
3	3795060	Motor-driven fan	1
4	61-3536	Condenser coil	1
5	61-3538	Indoor coil	1
6	3721672	Compressor	1
7	3762924	High pressure switch	1
8	3765020	Push button	1
9	3515630	Access connection	2
10	85-6789	Distributor	1
11	86-3566	Capillary tube n° 1	1
12	86-4004	Capillary tube n° 2	1
13	86-4078	Capillary tube n° 3	1
14	86-4079	Capillary tube n° 4	1
15	17-1887	Aluminium grid indoor coil	1
16	5330012	Seal retainer	4
17	5336112	Shutdown device	4
18	5390014	Closing pin	4
19	6739040	Nine-way connector	1
100	3771011	Connecting strip	1
101	6744638	Contacteur	1
102	6744616	Contacteur	1
103	6710410	Fuse holder	2
104	6730141	4 A Fuse	2
105	6831060	Fuse holder protection cover	2
106	6833050	Fuse holder threaded plug	2
107	6849845	Transformer	1
108	6820403	Overload relay	1
200	66-0505	Upper cover assembly	1
201	66-3526	Indoor corner assembly	2
202	13-5618	Compressor side exterior corner	1
203	13-5619	Fan side exterior corner	1
204	66-3529	Fan side crossbeam	1
205	13-5620	Outdoor side crossbeam	1
206	66-3528	Coils side crossbeam assembly	1

Spare Parts

RTC-10-A/H-38 ESP ed.01(04-98) R-22 (SERIAL A)



2/2

POS	ITEM	DENOMINATION	QUANTITY
			RTC-10-A/H-38 ESP ed.01
207	62-3527	Indoor coil support	1
208	17-1056	Outdoor coil connections cover	1
209	66-3533	Opened side panel assembly	1
210	66-3530	Indoor fan panel cover	1
211	66-3531	Closed side cover	2
212	17-5627	Closed side cover	1
213	17-9530	Opened side cover	1
214	17-9529	Opened side cover	1
215	17-5641	Closed side cover	1
216	17-0822	Outdoor coil support	1
217	17-0855	Outdoor coil support	1
218	17-5624	Indoor coil support	1
219	17-5623	Indoor coil support	1
220	63-4495	Drain pan	1
221	63-4475	Drain pan assembly	1
222	66-3525	Middle plate assembly	1
223	17-5625	Outdoor middle plate	1
224	3778564	Pressure switch support	1
225	6831030	Pressure switch protection cover	1
226	11-6905	Drainpipe protection	1
300	NE-2-0492	Isolator	2