


 Recambios RTH-20L-38 ed.01 (03-07)/ed.02 (09-07)/ed.03 (11-07) R-410A 662042003

 Spare Parts RTH-20L-38 ed.01 (03-07)/ed.02 (09-07)/ed.03 (11-07) R-410A 662042003

 Pièces détachées RTH-20L-38 ed.01 (03-07)/ed.02 (09-07)/ed.03 (11-07) R-410A 662042003



1/7



 Spare Parts RTH-20L-38 ed.01 (03-07)/
ed.02 (09-07)/ed.03 (11-07) R-410A

4/7

POS	ITEM	DENOMINATION	QUANTITY	
			RTH-20L-38 ed.01 662042003	RTH-20L-38 ed.02 662042003
1	003786044	Ambient thermostat (programmable)	1	1
2	003795049	Motor-driven fan	1	1
3	003795047	Motor-driven fan	1	1
4	61-9470	Outside coil assembly	1	1
5	61-9472	Indoor coil assembly	1	1
6	003794448	Two-way valve interconnection	2	2
7	001999564	Suction accumulator	1	1
8	003721914	Compressor	1	1
9	003794367	Four-way valve	1	1
10	003708240	Four-way valve trip coil	1	1
11	003762927	Low pressure switch	1	1
12	003762926	High pressure switch	1	1
13	003794468	Expansion valve	2	2
14	003794381	One way valve	2	2
15	022-08941-000	5/8" Distributor assembly with 6 pipes	1	1
16	022-08939-000	5/8" Distributor assembly with 7 pipes	1	1
17	003515630	Access connection	4	4
18	003785066	6000 mm sensor	4	4
19	16-14751	Aluminium grid outdoor coil	1	1
20	16-14750	Aluminium grid indoor coil	1	1
21	003737705	Air filter 440 x 395 x 20	2	2
22	003787101	Handle for handling	2	2
23	003778511	Fixation rubber support	1	1
24	006824905	Compressor crankcase heater	1	-
24	006824903	Compressor crankcase heater	-	1
25	003719108	Handle	2	2
26	003719114	Push lock	2	2
100	003770456	Power circuit connecting strip	1	1
101	003770454	Moving circuit connecting strip	1	1
102	006791210	Electronic board	1	1
103	006826810	Nylon separator	4	4
104	006849855	Transformer	1	1
105	006744617	Contacteur	2	2
106	006744639	Contacteur	1	1
107	006745250	Phases control relay	1	1
108	006776848	Themomagnetic switch	1	1
109	006776700	Switch	2	2
110	006776855	Main switch	1	1
111	006776814	Automatic switch	1	1
200	66-9466	Indoor upper cover assembly	1	1
201	66-9467	Outdoor upper cover assembly	1	1
202	66-9448	Comer assembly	4	4
203	17-14753	Fixer outdoor coil bracket	1	1
204	17-14752	Fixer indoor coil bracket	1	1
205	66-9457	Outdoor coil panel assembly	1	1
206	66-9468	Outdoor coil grid cover assembly	1	1
207	66-9452	Fan panel assembly	1	1
208	66-9458	Outdoor coil panel assembly	1	1
209	66-9454	Fan panel assembly	1	1
210	17-14775	Outdoor fan grid	1	1
211	66-9453	Outdoor fan panel cover	1	1
212	66-9451	Control box panel	1	1
213	66-9455	Outdoor fan panel assembly	1	1
214	66-9456	Indoor coil panel assembly	1	1
215	17-14754	Upper filter guide	1	1
216	17-14755	Bottom filter guide	1	1
217	17-14756	Fixer indoor coil bracket (middle plate side)	1	1

 Spare Parts RTH-20L-38 ed.01 (03-07)/
ed.02 (09-07)/ed.03 (11-07) R-410A



5/7

POS	ITEM	DENOMINATION	QUANTITY	
			RTH-20L-38 ed.01 662042003	RTH-20L-38 ed.02 662042003
218	63-9447	Outdoor drain pan assembly	1	1
219	63-9465	Indoor drain pan assembly	1	1
220	11-6905	Drainpipe protection	2	2
221	66-9461	Middle plate assembly	1	1
222	18-14780	Base support comer	1	1
223	18-14781	Base support comer	1	1
224	66-9460	Base indoor assembly	1	1
225	66-9459	Outdoor metal base	1	1
226	17-14517	Valve support	1	1
227	17-11120	Fan support	2	2
228	17-14779	Outdoor coil front stop	1	1
229	17-14778	Indoor coil front stop	1	1
230	17-14639	Components plate	1	1
231	17-14757	Fixer outdoor coil bracket (middle plate side)	1	1
232	66-9449	Control box assembly	1	1
233	66-9450	Central post assembly	1	1