



POS	ITEM	DENOMINATION	QUANTITY
			RTH-15 A/I-38 ESP ed.01
1	3786046	Ambient thermostat	1
2	3795044	Motor-driven fan	2
3	61-0458	Outdoor coil	1
4	61-0456	Indoor coil	1
5	3721678	Compressor	1
6	1999567	Suction accumulator	1
7	3762950	High pressure switch	1
8	65-0787	Distributor	2
9	86-0358	Capillary tube	1
10	86-0359	Capillary tube	1
11	86-0360	Capillary tube	1
12	86-0944	Capillary tube	1
13	3515630	Access connection	2
14	3794375	Four-way valve	1
15	6712524	Four-way valve trip coil	1
16	3794383	One way valve	4
17	3785052	1700 mm Sensor	2
18	3785054	3500 mm Sensor	1
19	17-1884	Aluminium grid outdoor coil	1
20	17-1885	Aluminium grid indoor coil	1
21	6739040	Nine-way connector	2
100	3770532	Connecting strip	1
101	6744616	Contacteur	2
102	6744643	Contacteur	1
103	6820404	Overload relay	1
104	6791024	Electronic board	1
105	6826810	Nylon separator	15
200	66-5044	Upper cover assembly	1
201	66-3526	Indoor corner assembly	2
202	66-4407	Compressor side outdoor corner assembly	1
203	66-4445	Fan side exterior corner	1
204	66-3529	Fan side crossbeam	1
205	66-4409	Outdoor crossbeam assembly	1
206	66-3528	Coils side crossbeam assembly	1
207	62-3788	Indoor coil support	1

# Spare Parts

## RTH-15 A/I-38 ESP ed.01 (04-98) R-22 (SERIAL A)



2/2

POS	ITEM	DENOMINATION	QUANTITY
			RTH-15 A/I-38 ESP ed.01
208	17-1056	Outdoor coil connections cover	1
209	66-3794	Opened side panel assembly	1
210	66-3790	Indoor fan panel cover	1
211	66-3791	Closed side cover	3
212	66-4447	Closed side cover	1
213	66-6398	Opened side cover	1
214	17-9531	Opened side cover	1
215	17-6096	Outdoor coil support	1
216	17-0880	Outdoor coil support	1
217	17-6095	Indoor coil support	1
218	17-0883	Indoor coil support	1
219	63-4492	Drain pan	1
220	63-4448	Drip pan assembly	1
221	62-3787	Intermediate middle plate assembly	1
222	17-6097	Outdoor middle plate	1
223	11-6905	Drainpipe protection	2
300	NE-2-2285	Isolator	2