




BY JOHNSON CONTROLS

VIR Spare Parts Manual



Spare Parts Manual

Ref.: N-40382_EN 0511





Index

1	Outdoor assembly.....	1
2	Cooling circuits and coils.....	5
3	Ventilation.....	9



1

Outdoor assembly

VIR-25A



VIR-40A/45A/60A/75A/90A




Pos.	Part	25A	40A	45A	60A	75A	90A
1	Upper panel assembly	403055	404475	404474	404474	392374	392374
2	Front fan support	403086	404185	404181	404181	394676	394676
3	Front left-hand edge	403052	404495	404487	404487	395295	395295
4	Side panel assembly	403056	404499	404491	404491	392388	392388
5	Left-hand rear edge	403053	404496	404488	404488	395296	395296
6	Filter handle	394647	394647	394647	394647	394647	394647
7	Filter side guide	403087	404269	404258	404258	392217	392217
8	Right-hand rear edge	403054	404497	404489	404489	395297	395297
9	Drain pan	403039	404483	404481	404481	392380	392380
10	Base assembly	403037	404482	404480	404480	392379	392379
11	Carry handle	369980	369980	369980	369980	369980	369980
12	Pipe duct plate	403085	404272	394833	394833	394833	394833
13	Front right-hand edge	403040	404494	404486	404486	395294	395294
14	Right-hand front panel	403057	404500	404492	404492	395299	395299
15	Front centre edge	–	404498	404490	404490	395298	395298
16	Left-hand front panel	–	404501	404493	404493	395300	395300


2

Cooling circuits and coils




VIR-25A



VIR-40A



VIR-45A/60A/75A/90A






Pos.	Part	25A	40A	45A	60A	75A	90A
1	Upper coil protector	403083	404270	404257	404257	394831	394831
2	Filter assembly	402247	391721	391845	391845	394157	394157
3	Lower coil protector	403084	404271	396213	396213	392216	392216
4	Coil assembly (Blue Fin)	432606	432610	432614	432614	432620	432620
4	Coil assembly	403059	404455	404448	404448	395234	395234
4	Coil assembly (Cu-Cu)	428983	428987	428991	428991	432573	432573
5	Stem valve	368812	368812	368812	368812	368812	368812
6	7-pipe distributor	-	371671	-	-	-	-
7	4-pipe distributor	371669	-	-	-	-	-
8	Pipe support	-	404259	394832	394832	394832	394832
9	Clamp	369006	369006	369006	369006	369001	369001
10	Clamp	369009	369009	369013	369013	369014	369014
11	One-way valve	370022	370023	370022	370023	370023	370023
12	Expansion valve	370057	370053	370057	370058	370053	370053
13	3-pipe distributor	-	371670	-	-	-	-
14	5/8" distributor assembly with 8 pipes	-	-	371676	371676	-	-
15	Clamp	-	-	369014	369014	-	-
16	Spacer	-	-	408973	408973	-	-
17	5/8" distributor assembly with 6 pipes	-	-	-	-	371949	371949


3

Ventilation

VIR-25A



VIR-40A/45A/60A/75A/90A



Pos.	Part	25A	40A	45A	60A	75A	90A
1	Centrifugal fan	370074	370080	370079	370079	370096	370096
2	Fan pulley	369787	369791	390607	390601	396154	396153
3	Fan belt	370143	370143	370144	370144	370161	370161
4	Fan motor	371192	371199	371199	371193	371202	371200
5	Motor flange	508451	508452	508452	508452	508454	508454
6	Motor pulley	369793	396232	390596	396232	390598	390604