



 Recambios RTH-25L-38 ed.01 (03-07)/ed.02 (10-07) R-410A 662042503
 Spare Parts RTH-25L-38 ed.01 (03-07)/ed.02 (10-07) R-410A 662042503
 Pièces détachées RTH-25L-38 ed.01 (03-07)/ed.02 (10-07) R-410A 662042503




1/7



 Spare Parts RTH-25L-38 ed.01 (03-07)/
ed.02 (10-07) R-410A

4/7

POS	ITEM	DENOMINATION	QUANTITY	
			RTH-25L-38 ed.01 662042503	RTH-25L-38 ed.02 662042503
1	003721918	Compressor	1	1
2	001999571	Suction accumulator	1	1
3	61-9483	Condenser coil assembly	1	1
4	61-9480	Evaporator coil assembly	1	1
5	003795049	Motor-driven fan	1	1
6	003795031	Centrifugal fan	1	1
7	006792525	Fan motor	1	1
8	003761031	Speed varying pulley	1	1
9	003761068	Fan pulley	1	1
10	004918098	Fan belt	1	1
11	003778539	Fan top motor support	1	1
12	003794448	Two-way valve interconnection	2	2
13	003794367	Four-way valve	1	1
14	003708240	Four-way valve trip coil	1	1
15	003515630	Access connection	4	4
16	003762926	High pressure switch	1	1
17	003762927	Low pressure switch	1	1
18	003794468	Expansion valve	2	2
19	003794381	One way valve	2	2
20	003778511	Fixation rubber support	1	1
21	003785064	3500 mm sensor	4	4
22	003786044	Ambient thermostat (programmable)	1	1
23	16-14824	Aluminium grid outdoor coil	1	1
24	006824903	Compressor crankcase heater	-	1
24	006824905	Compressor crankcase heater	1	-
25	003787101	Handle for handling	2	2
26	003719108	Handle	2	2
27	003719114	Push lock	2	2
28	003737736	Air filter 695 x 410 x 25	2	2
29	022-06846-011	9 pipes distributor	1	1
30	022-08941-000	5/8" Distributor assembly with 6 pipes	1	1
31	003581512	Clamp	2	2
32	003581515	Clamp	-	2
32	003581513	Clamp	2	-
100	003770457	Power circuit connecting strip	1	1
101	003770455	Moving circuit connecting strip	1	1
102	006791210	Electronic board	1	1
103	006826810	Nylon separator	4	4
104	006849855	Transformer	1	1
105	006744652	Contactora	1	1
106	006744617	Contactora	2	2
107	006776814	Automatic switch	1	1
108	006776855	Main switch	1	1
109	006776700	Switch	2	2
110	006776840	Thermomagnetic switch	1	1
111	006745250	Phases control relay	1	1
200	66-9491	Cover top Assy	1	1
201	66-9492	Cover top Assy	1	1
202	66-9502	Comer assembly	4	4
203	66-9504	Fan post assembly and outdoor coil	1	1
204	66-9506	Indoor coil fan post assembly	1	1
205	66-9510	FALTA TRADUCCIÓN	1	1
206	66-9513	Control box post assembly	1	1
207	66-9505	Control box post assembly	1	1
208	17-14825	Coil bracket	4	4
209	66-9501	Outdoor coil panel assembly	1	1
210	66-9507	Air intake cover assembly	1	1

 Spare Parts RTH-25L-38 ed.01 (03-07)/
ed.02 (10-07) R-410A



5/7

POS	ITEM	DENOMINATION	QUANTITY	
			RTH-25L-38 ed.01 662042503	RTH-25L-38 ed.02 662042503
211	66-9495	Indoor motor panel assembly	1	1
212	66-9493	Fan panel	1	1
213	66-9508	Fan grid cover assembly	1	1
214	66-9500	Outdoor coil panel assembly	1	1
215	66-9499	Outdoor fan panel cover	1	1
216	17-14827	Outdoor air discharge panel	1	1
217	66-9498	Outdoor fan panel cover	1	1
218	66-9496	Control box panel	1	1
219	66-9497	Indoor coil panel assembly	1	1
220	66-9494	Fan panel	1	1
221	62-9486	Filter frame panel assembly	1	1
222	17-14872	Upper filter guide	1	1
223	17-14873	Bottom filter guide	1	1
224	63-9488	Drain pan assembly	1	1
225	63-9487	Drain pan assembly	1	1
226	11-6905	Drainpipe protection	2	2
227	66-9503	Motor plate post assembly	1	1
228	66-9514	Middle plate assembly	1	1
229	17-14826	Fan support	2	2
230	18-14828	Indoor Base clamp crossbeam	1	1
231	18-14831	Central base clamp crossbeam	1	1
232	18-14832	Outdoor base clamp crossbeam	1	1
233	66-9489	Metal base	1	1
234	66-9490	Metal base	1	1
235	18-14830	Base clamp crossbeam	1	1
236	18-14829	Base clamp crossbeam	1	1
237	17-14517	Valve support	1	1
238	17-14786	Components plate	1	1
239	11-14823	Fan tensioner support	1	1
240	66-9511	Indoor fan panel support	1	1
241	66-9512	Outdoor fan panel support	1	1
242	66-9573	Control box assembly	1	1
243	17-14797	Tube support	2	2
244	66-9571	Fan grid cover assembly	1	1